

Problems? Call our Installation Helpline on ++(44) 0845 862 6400

1

Create hole in floor.

WARNING - ONLY TO BE INSTALLED BY A QUALIFIED ELECTRICIAN

Ensure cutout dimensions are adhered to or fitting will not sit flush into the ground

VAPOUR BARRIER MUST BE SUITABLE FOR 90°C

Before starting, the mains supply must be off

Take care with glass top, as it can chip if dropped.

Dimensions in mms

2

TURN OFF MAINS POWER WHEN WIRING!

Feed cable into recess.

3

Transformer

For wiring and cable lengths, refer to wiring diagram for transformer used

Complete wiring for all Q.

4

click!

High Intensity Light Source! Do not stare into the beam!

Power Up Q and check they illuminate. If they do not, check all wiring and connections.

5

Place Q into cavity. Seal with appropriate sealant or grout, if required.

6

Installation complete. If you have any problems please contact ACDC.

ACDC Lighting Systems Ltd, Innovation Works, Gisburn Road, Barrowford, Lancashire, BB9 8NB

sales@acdcighting.co.uk

www.acdcighting.co.uk